背面

55mm 55mm

80mm

XDXCLUSIVE®

Fiko wireless charging portfolio A5

XD Connects B.V.
Lange Kleiweg 6-28
2288 GK Rijswijk,The Netherlands
1F,iCentrum,Holt Street,
Birmingham,B7 4BP,England

10mm

Copyright© XD P774.081

正面

USING THE POWERBANK
- Plug the cable into the USB port on the power bank, the other end goes into your device.
- Your device will show a charging condition in the usual way. blue light will show on the power bank.
- The power bank will take approximately two hours to charge your mobile device to 95%.
- Once the device is charged your device, recharge the power bank before using again.

USING THE WIRELESS CHARGER
- Make sure your phone is compatible for wireless charging.
- Put your wireless charging enabled device on the wireless charging surface.

WARNING!
- Do not vigorously shake, hit or throw the product.
- If the power bank is not used for long time, please charge/discharge it once every three months to maintain the quality of the product.
- Some phone cases may block the wireless charging
- Do not place other materials, like metal objects, magnets, and magnetic stripe cards, between the mobile device and the wireless charger pad.
- Check your mobile device's battery percentage using the charging icon on the screen when it is charging.
- When the mobile device is not placed on the charging surface accurately, your mobile device may not charge properly.
- If you use the wireless charger in areas with weak network coverage, you may lose your network reception.
- Keep the product away from water, moisture or heat sources
- This is not a toy, not suitable for children under the age of 7

EU Declaration of Conformity

ENGLISH
Zwei Geräte können gleichzeitig aufgeladen werden. Das Gerät muss mit dem Powerbank verbunden werden. Die Powerbank kann mit einem Gerät aufgeladen werden. Die Powerbank kann mit einem Gerät aufgeladen werden. Die Powerbank kann mit einem Gerät aufgeladen